SUZUKI ASSEMBLERS MALAYSIA SDN. BHD. (10789-W)

1412, Plot No. 281, Prai Industrial Complex
13600 Prai, P.W., Malaysia
Tel: 04-397 7453, 04-399 0457
Fax: 04-397 7635

Spare Parts Department
Tel: 04-397 7091 Fax: 04-397 7831

Service Department
Tel: 04-397 7314 Fax: 04-397 7441

9900BC46G10C000

SUZUKI

UY125SC

STEP125

9900BC46G10C000

SUZUKI
PARTS CATALOGUE

UY125SC

2007 - 11

1st EDITION

00 PC Step UY125SC COVER .p65 1

11/28/07, 9:36 AM

SUZUKI

STEP 125

MODEL CODE UY125SC

YEAR NOVEMBER 2007

COVER SET, body (N.Titan Black / B. White)

REF. NO.	PART NAME	PART NO.	PARTS COLOUR CODE			
			106	**158**	**280**	**904**
			N.Titan Black	Hyper Pink	Macho B.Blue	B.White
1	COVER,frame RH	47111-46G20-904	-	-	-	√
2	COVER,frame LH	47211-46G20-904	-	-	-	√
3	SHIELD, leg front	48111-46G00-106	√	-	-	-
4	FENDER, front	53111-46G20-106	√	-	-	-
5	COVER, handle front	56311-46G31-106	√	-	-	-
	COVER SET, body	**94400M46G20-106**				

COVER SET, body (H.Pink / N. Titan Black)

REF. NO.	PART NAME	PART NO.	PARTS COLOUR CODE			
			106	**158**	**280**	**904**
			N.Titan Black	Hyper Pink	Macho B.Blue	B.White
1	COVER,frame RH	47111-46G20-106	√	-	-	-
2	COVER,frame LH	47211-46G20-106	√	-	-	-
3	SHIELD, leg front	48111-46G20-158	-	√	-	-
4	FENDER, front	53111-46G00-158	-	√	-	-
5	COVER, handle front	56311-46G31-158	-	√	-	-
	COVER SET, body	**94400M46G20-158**				

COVER SET, body (Macho B. BLue / B. White)

REF. NO.	PART NAME	PART NO.	PARTS COLOUR CODE			
			106	**158**	**280**	**904**
			N.Titan Black	Hyper Pink	Macho B.Blue	B.White
1	COVER,frame RH	47111-46G20-904	-	-	-	√
2	COVER,frame LH	47211-46G20-904	-	-	-	√
3	SHIELD, leg front	48111-46G20-280	-	-	√	-
4	FENDER, front	53111-46G00-280	-	-	√	-
5	COVER, handle front	56311-46G31-280	-	-	√	-
	COVER SET, body	**94400M46G20-280**				

INFORMATION ILLUSTRATION INDEX 1
ENGINE TRANSMISSION 2
ELECTRICAL 3
BODY 4
PARTS NUMBER INDEX 5

PREFACE

When it becomes necessary to replace parts on SUZUKI MOTORCYCLES, always use SUZUKI GENUINE PARTS which have passed a strict inspection which guarantees quality performance.

This parts catalogue covers the list of all service parts for SUZUKI UY125SC

INSTRUCTIONS FOR QUOTING THE CATALOGUE

1. **DIMENSIONS**
   Dimensions of the parts in this catalogue are indicated in unit milimeters.

2. **ABBREVIATIONS**
   Abbreviations used in this catalogue are as follows:

AR	: As required
ASSY	: Assembly
E. No.	: Engine number
F. No.	: Frame number
D	: Diameter of material
ID	: Inside diameter
OD	: Outside diameter
L	: Length
LH	: Left hand side
RH	: Right hand side
~100045	: Up to F. No. A100-A100045
100046~	: From F. No. A100-A100046

12 x 34 x 5.6------- Figures in the description column show the dimensions of parts.
| | |
ID OD T(or W, L)

NT	: Number of teeth
OPT	: Optional
OS	: Over size
STD	: Standard
T	: Thickness
US	: Under size
W	: Width

→12345-56781 (Parts No.) : indicates that the parts number was changed to 12345-56781 and the new parts numbers are interchangeable with the former ones but the former ones are not interchangeable with new ones.

←12345-56781 (Parts No.) : indicates that the former and new parts are interchangeable with each other and both are usable.

3. **INNER PARTS OF ASSEMBLY**
Parts name with a dot (.) in front as shown in the description column indicates the component of the assembly also available individually.

4. **MODIFICATION NOTICE**
A parts bulletin will be sent to you on all occasions when changes in parts occur, including interchangeable modifications between new parts and old ones.

5. **NOTE**
5-1 There are some different parts from those of productions models among spare parts for the administrative reasons and common use of them with other models.

5-2 In respect of rubber hoses and vinyl tubes, please be sure to use them by cutting off according to the length mentioned on parts catalogue or what is actually required on the vehicle.

5-3 Note that the drawings on the illustration on page are for ready reference of spare parts number, not to be used as an assembly manual. When assembling, use “SUZUKI SERVICE MANUAL”.

6. **SERIAL FRAME NUMBER**
UY125SC : PMSCF48J - 07YA00001~

7. **STD. COLOR CHART**

COLOR NO.	PARTS COLOR DESCRITION
019	ORGA BLACK
106	NEW TITAN BLACK
158	HYPER PINK
280	MACHO BRIGHT BLUE
334	CRYSTAL SILVER
339	BRILLIANT SILVER
904	BRILLIANT WHITE

FIG. 1



FIG. 2



FIG. 3



FIG. 4



FIG. 5



FIG. 5A



FIG. 6



FIG. 7



1

FIG. 8



FIG. 9



FIG. 10



FIG. 10



FIG. 11



FIG. 12



FIG. 13



FIG. 14



FIG. 15



FIG. 16



FIG. 17



FIG. 18



FIG. 19



FIG. 20



FIG. 21



FIG. 22



1

FIG. 23



FIG. 24



FIG. 25



FIG. 26



FIG. 27



FIG. 28



FIG. 29



FIG. 30



FIG. 31



FIG. 32



FIG. 33



FIG. 34



FIG. 35



FIG. 36



FIG. 37



FIG. 38



1

FIG. 39



FIG. 40



FIG. 41



FIG. 42



FIG. 43



FIG. 44



FIG. 45



FIG. 46



FIG. 47



FIG. 48



FIG. 49



FIG. 50



FIG. 1



FIG. 1 CYLINDER HEAD COVER

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11171-46G00	COVER, cylinder head	1	
2	11173-46G00	GASKET, cylinder head cover 1		
3	09106-07003	BOLT, head cover	2	
4	11191-27E20	WASHER, head cover	2	
5	11180-46G00	COVER, breather	1	
6	11177-46G00	GASKET, breather cover	1	
7	01547-0620A	BOLT, breather cover	4	
8	11186-46G00	SEPARATOR, oil breather	1	

FIG. 2

2



FIG. 2 CYLINDER HEAD

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11110-46G00	HEAD ASSY, cylinder	1	
2	09381-10004	RING, valve guide	2	
3	11141-46G00	GASKET, cylinder head	1	
4	11135-46G00	PLATE, oil separator	1	
5	08316-1008B	NUT, cylinder head	4	
6	09160-08164	WASHER, cylinder head nut	2	
7	01421-0630A	BOLT, cylinder head stud side	1	
8	01547-0610A	PLUG, head oil gallery	1	
9	54494-09G00	NUT, cylinder head side	3	
10	04211-11129	PIN, cylinder head knock	2	
11	09482M00568	SPARK PLUG (C6HSA, NGK)	1	
12	13110-46G10	PIPE, intake	1	
13	13125-46G00	O-RING, (D:2.4, ID:25.7)	1	
14	01547-0635A	BOLT, intake pipe	2	
15	13170-46G10	CLAMP, intake pipe	1	
16	12862-33G00	RETAINER, camshaft	1	
17	02122-06128	SCREW, camshaft retainer	1	

FIG. 3



FIG. 3 CYLINDER

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11211-33G01-0F0	CYLINDER	1	
2	11241-46G00	GASKET, cylinder	1	
3	09108-08272	STUD BOLT (L:185)	4	
4	01421-0695B	STUD BOLT (6x95)	2	
5	04211-11129	PIN, cylinder knock	2	

FIG. 4



FIG. 4 CRANKCASE

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11310-46820	CRANKCASE SET RH	1	
2	11315-46G00	BUSH, engine mount	1	
3	11320-46830	CRANKCASE SET LH	1	
4	11315-46G00	BUSH, engine mount	1	
5	09319-10032	BUSH, rear shock abs	1	
6	01547-0655A	BOLT, crankcase	6	
7	01547-0675A	BOLT, crankcase	3	
8	09206-08008	PIN, crankcase	2	
9	11325-46G00	TUBE, crankcase	1	
10	11326-46G00	GROMMET, crankcase tube NO.1	1	
11	11327-46G00	GROMMET, crankcase tube NO.2	1	
12	16912-46G00	UNION, gear box breasther	1	
13	11432-46G00	HOSE, breather	1	
14	09401-10401	CLIP, breather hose	1	
15	11971-46G00	PLUG, gear box oil filler	1	
16	09280-14003	O-RING, gear box oil filler	1	
17	01500-1016A	PLUG, oil drain	1	
18	09168-10002	GASKET, oil drain plug	1	
19	01550-0812A	PLUG, oil check	1	
20	09168-08008	GASKET, oil check plug	1	
21	64711-09G00	BOLT, engine mount	1	
22	08316-1012B	NUT, engine mount	1	
23	01550-0812A	PLUG, gear box oil drain	1	
24	09168-08008	GASKET, gear box oil drain	1	

FIG. 5



FIG. 5 CRANKCASE COVER

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11340-46G00	COVER, clutch	1	
2	11482-46G00	GASKET, clutch cover	1	
3	11346-46G00	PLATE, clutch cover air intake	1	
4	01547-0612B	BOLT, clutch cover air intake	3	
5	01547-0625B	BOLT, clutch cover	9	
6	01547-0630B	BOLT, clutch cover	1	
7	09206-08008	PIN, clutch cover	2	
8	11431-46G00	COVER, gear box	1	
9	11484-46G00	GASKET, gear box cover	1	
10	01547-0625B	BOLT, gear box cover	7	
11	09206-08008	PIN, gear box cover	2	
12	11381-46G00	COVER, belt cooling	1	
13	11382-46G10	FILTER, belt cooling	1	
14	11383-46G00	O-RING, belt cooling cover	1	
15	11386-46G00	PLATE, belt cooling cover	1	
16	01547-0620B	BOLT, belt cooling cover	3	
17	01547-0665B	BOLT, belt cooling cover	4	
18	11351-46G01	COVER, crankshaft RH	1	
19	11483-46G00	GASKET, crankshaft cover RH	1	
20	01547-0630B	BOLT, crankshaft cover RH	7	
21	01547-0660B	BOLT, crankshaft cover RH	2	
22	01547-06307	BOLT, crankshaft cover RH	1	
23	09206-08008	PIN, crankshaft cover RH	2	
24	11971-33G01	GAUGE, oil level	1	
25	09280-17003	O-RING, oil level gauge	1	
26	11410-46G00	DUCT, belt cooling	1	
27	11385-46G00	O-RING, belt cooling duct	1	

2

FIG. 5



FIG. 5 CRANKCASE COVER

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
28	11307-46G00	COVER, clutch upper	1	
29	11361-46G10	COVER, belt cooling duct NO.1	1	
30	11362-46G00	COVER, belt cooling duct NO.2	1	
31	11363-46G00	MOLD, belt cooling duct cover	1	
32	03141-0516A	SCREW, belt cooling duct cover	2	
33	11390-46G00	BRACKET, clutch cover upper	1	
34	01550-0830B	BOLT, clutch cover upper bracket	1	
35	01550-0845B	BOLT, clutch cover upper bracket	1	
36	01547-0620B	BOLT, belt cooling cover	2	
37	01547-0616B	BOLT, clutch cover upper	2	
38	11347-46G00	SPACER, air intake plate	1	
39	09409-08308	CLIP, clutch cover upper	1	
40	01547-0625B	BOLT, water drain	1	
41	11373M46G00	CUSHION, clutch cvr, upper	1	

FIG. 6



FIG. 6 CRANKSHAFT

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12200-46G01	CRANKSHAFT ASSY	1	
2	12221-46G00	CRANKSHAFT, RH	1	
3	12261-46G00	CRANKSHAFT, LH	1	
4	12511-33G00	PLATE, oil guide	1	
5	09180-19013	SPACER, crankshaft LH	1	
6	12160-46811	CON-ROD SET	1	
7	12161-46G00-0C0	ROD, connecting	1	
8	12210-46G00-0A0	PIN, crank	1	
9	09263-28034-0B0	BEARING, crank pin	1	
10	09262-35079	BEARING, crankshaft RH	1	
11	09262-25122	BEARING, crankshaft LH	1	
12	09283-22033	OIL SEAL RH	1	
13	09283-25095	OIL SEAL LH	1	
14	12100-46G10-0F0	PISTON SET (STD)	1	
15	12111-46G11-0F0	PISTON (STD)	1	
16	12140-33G10	RING SET, piston (STD)	1	
17	12151-20G00	PIN, piston	1	
18	09381-14001	CIRCLIP	2	
19-1	09181-35103	SHIM (T:0.60)	1	
19-2	09181-35026	SHIM (T:0.65)	1	
19-3	09181-35104	SHIM (T:0.70)	1	
19-4	09181-35105	SHIM (T:0.75)	1	
19-5	09181-35106	SHIM (T:0.80)	1	
19-6	09181-35107	SHIM (T:0.85)	1	
19-7	09181-35108	SHIM (T:0.90)	1	

2

FIG. 7



FIG. 7 STARTER CLUTCH

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12611-46G00	GEAR, starter idle	1	
2	09206-13007	PIN, starter idle gear	1	
3	12600-46820	CLUTCH SET, starter	1	
4	12633-05300	PIECE, starter clutch roll	3	
5	09261-10007	ROLLER, starter clutch	3	
6	09440-03007	SPRING, starter clutch	3	
7	12649-30D00	SHIM, starter clutch hub	1	
8	07130-0612A	BOLT, starter clutch	3	

FIG. 8



FIG. 8 CAM SHAFT/VALVE

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12710-46G00	CAMSHAFT SET	1	
2	09262-15041	BEARING, camshaft LH	1	
3	08113-69050	BEARING, camshaft RH	1	
4	12741-33G10	SPROCKET, camshaft	1	
5	09106-05028T	BOLT, sprocket (5X15)	2	
6	09261-05005	PIN, sprocket angle	1	
7	09206-08008	PIN, sprocket angle	1	
8	12951-33G10	CAM, decompression	1	
9	12954-33G00	STOPPER, decomp cam	1	
10	12955-33G00	WASHER, decomp shaft	1	
11	12725-33G00	SPRING, decomp cam	1	
12	12840-33G30	ARM, valve rocker	2	
13	12842-49201	SCREW, tappet adjusting	2	
14	12843-27A00	NUT, tappet adjusting	2	
15	12861-33G10	SHAFT, rocker arm	2	
16	12911-28G20	VALVE, intake	1	
17	12912-33G10	VALVE, exhaust	1	
18	12921-28G40	SPRING, valve	2	
19	12931-09G00	RETAINER, valve spring	2	
20	12932-09G00	COTTER, valve	4	
21	12933-09G00	SEAT, valve spring	2	
22	09289-05008	OIL SEAL	2	

FIG. 9

2



FIG. 9 CAM CHAIN

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12760-20G00	CHAIN, cam shaft drive	1	
2	12771-33G10	GUIDE, cam chain	1	
3	12811-28G10	TENSIONER, cam chain	1	
4	09103-06247	BOLT, cam chain tensioner	1	
5	09168-06004	WASHER, tensioner bolt	1	
6	12830-46G00	ADJUSTER, tensioner	1	
7	12837-46G00	GASKET, tensioner adjuster	1	
8	01547-0620B	BOLT, tensioner adjuster	2	

FIG. 10



FIG. 10 CARBURETOR

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13200-46G10	CARBURETOR ASSY	1	
2	13507-25G00	DIAPHRAGM	1	
3	13502-46G10	COVER, diaphragm	1	
4	13502-46G00	PISTON, valve	1	
5	13573-46G00	SPRING	1	
6	13418-12F40	HOLDER	1	
7	13481-23F00	SPRING	1	
8	13382-23F00	WASHER	2	
9	13533-98410	E-RING	1	
10	13387-23F00	RING	1	
11	13383-46G30	JET, needle (4DN17-2)	1	
12	13258-23F00	O-RING	1	
13	13254-20010	PIN	1	
14	02112-04083	SCREW	1	
15	09491-97007	MAIN JET (97.5)	1	
16	13341-46G00	NEEDLE JET (E-2M, 906)	1	
17	13240-47E00	FLOAT ASSY	1	
18	13342-46G00	HOLDER, jet	1	
19	13412-46G00	STARTER BODY	1	
20	02112-35127	SCREW	2	
21	09492-15011	PILOT, jet (15)	1	
22	13267-46G00	ADJUSTER SCREW ASSY	1	
23	13271-24D00	SPRING	1	
24	13602-38A10	SCREW	3	
25	13683-36A00	HOSE	1	
26	13279-23F30	ADJUSTER, screw	1	
27	13268-47070	SPRING	1	

2

FIG. 10



FIG. 10 CARBURETOR

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
28	13370-46G00	SEAT, valve	1	
29	13375-88C00	CLIP	1	
30	13291-29900	WASHER	1	
31	13295-29900	O-RING	1	
32	13681-04010	CAP	1	
33	13418-43410	GUIDE, holder	1	
34	13417-01010	SPRING	1	
35	13411-46G00	PLUNGER ASSY	1	
36	13258-46G00	O-RING	1	
37	13602-47090	SCREW	2	
38	13278-47090	O-RING	1	
39	13601-04188	SCREW	1	
40	13274-46G00	CLIP	1	
41	13432-44120	WASHER	1	
42	13247-25G00	SCREW	1	
43	13686-46G00	HOSE	1	
44	13509-17C00	O-RING	1	
45	13551-46G00	NEEDLE ASSY	1	
46	13275-46G00	PLATE, carburetor	1	
47	13593-46G00	RING	1	
48	13617-12C00	E-RING	1	
49	13683-46G00	HOSE	1	

FIG. 11



FIG. 11 AIR CLEANER

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13700-46G01	CLEANER ASSY, air	1	
2	13720-46G01	CASE, air cleaner	1	
3	13746-46G00	GASKET	1	
4	13780-46G01	FILTER ASSY, air cleaner	1	
5	13821-46G00	SLIDER, air ceaner	1	
6	13824-18910	CLIP	1	
7	13826-46G00	CLAMP	1	
8	13871-09G00	PLUG, drain	1	
9	13881-46G00	TUBE, outlet	1	
10	03541-0520B	SCREW	4	
11	13853-46G00	TUBE, breather	1	
12	09401-14301	CLIP	2	
13	13740-46G00	CAP, air cleaner	1	
14	09160-06028	WASHER, air cleaner	1	
15	01547-0625A	BOLT, air cleaner	1	
16	01547-0620A	BOLT, air cleaner	1	

FIG. 12



FIG. 12 MUFFLER

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	14181M46G00	GASKET, exhaust pipe	1	
2	07130-0820B	BOLT, exhaust pipe	2	
3	14310-46G40T	BODY COMP, muffler	1	
4	14780-46G00	COVER, muffler	1	
5	09139-06091	SCREW, muffler cover	2	
6	09160-06028	WASHER, muffler cover	2	
7	09180-06256	SPACER, muffler cover	2	
8	09320-08051	CUSHION, muffler cover	2	
9	01550-0835B	BOLT, muffler support	2	
10	09320M12032	CUSHION, muffler support	2	
11	09180-08151	SPACER, muffler support	2	
12	09160-08163	WASHER, muffler support	2	

FIG. 13



FIG. 13 OIL PUMP

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	16400-46G00	PUMP ASSY, engine oil	1	
2	02122-06258	SCREW, oil pump	2	
3	16331-46G00	GEAR, oil pump driven	1	
4	16422-20E00	WASHER, oil pump driven	1	
5	16423-20E00	E-RING, oil pump driven	1	
6	16421-20E00	PIN, oil pump driven	1	
7	16422-46G10	COVER, oil pump	1	
8	16310-46G00	CHAIN ASSY, oil pump drive	1	
9	16510-05240	FILTER, engine oil	1	
10	16512-09G00	CAP, oil filter	1	
11	16520-09402	STRAINER, engine oil	1	
12	16523-20E00	CAP, oil strainer	1	
13	16524-46G00	GASKET, oil strainer cap	1	
14	09280-13007	O-RING, oil filter	1	
15	09280-54001	O-RING, oil filter cap	1	
16	16519-09G00	SPRING, oil filter	1	
17	01547-0616A	BOLT, oil filter cap	3	
18	01547-0625A	BOLT, oil strainer cap	2	

FIG. 14



FIG. 14 COOLING FAN

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17110-46G00	FAN, cooling	1	
2	17116-46G00	HOLDER, cooling fan	1	
3	17121-46G00	COWLING, cylinder	1	
4	17122-46G00	MOLD, cylinder cowling	1	
5	17123-46G00	DAMPER, cylinder cowling	1	
6	17131-46G00	COWLING, fan NO.1	1	
7	17141-46G00	COWLING, fan NO.2	1	
8	17134-46G00	DAMPER, fan cowling NO.2	1	
9	17135-46G00	DAMPER, fan cowling NO.3	1	
10	17132-46G00	MOLD, fan cowling	1	
11	17133-46G00	DAMPER, fan cowling NO.1	1	
12	17134-20E00	SPACER, fan cooling	3	
13	01550-0612A	BOLT, cooling fan	3	
14	17125-46G00	GROMMET, intake pipe hose	1	
15	03541-0620A	SCREW, fan cowling	2	
16	02112-1625B	SCREW, fan cowling	2	
17	03541-0516B	SCREW, fan cowling	2	
18	02112-1625A	SCREW, cylinder cowling	1	
19	08313-2010A	NUT, cooling fan	1	
20	09168-10017	GASKET, cooling fan nut	1	

FIG. 15



FIG. 15 AIR VALVE

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	18450-06G00	VALVE ASSY, 2nd air reed	1	
2	18461-46G01	HOSE, 2nd air valve	1	
3	18510-46G00	VALVE ASSY, air cut	1	
4	18531-46G00	COVER, 2nd air reed valve	1	
5	18750-46G00	PROTECTOR, reed valve cover	1	
6	18711-46G01	HOSE, 2nd air cleaner	1	
7	18762-46G00	HOSE, 2nd air valve vacuum	1	
8	09180-06166	SPACER, 2nd air valve sprt	1	
9	09320-07014	CUSHION, 2nd air valve	1	
10	01547-0620A	BOLT, 2nd air valve	1	
11	09401-15101	CLIP, 2nd air hose	4	
12	01547-0620A	BOLT, 2nd air cover	2	

3

FIG. 16



FIG. 16 CLUTCH

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21111-33G00	FACE, fixed drive	1	
2	21120-33G00	FACE, movable drive	1	
3	21125-33G00	SPACER, movable driven	1	
4	21210-33G00	FACE, fixed driven	1	
5	21240-33G00	FACE, movable driven	1	
6	21243-33G00	SPRING, movable driven	1	
7	21245-33G00	O-RING, movable driven	2	
8	21248-33G00	PIN, movable driven	3	
9	21249-33G00	SPACER, movable driven pin	3	
10	21431-33G00	PLATE, movable driven	1	
11	21471-33G00	SHEET, movable driven	1	
12	21481-14F00	DAMPER, movable drive plate	3	
13	21650-33G10	ROLLER, movable drive	6	
14	09262-15035	BEARING, fixed drvn LH	1	
15	09263-20093	BEARING, fixed drvn RH 20x2 1		
16	09284-34003	SEAL, movable driven oil 34 2		
17	09381-24005	CIRCLIP, fixed driven	1	
18	21220-20E21	HOUSING, clutch	1	
19	21501-46G00	CLUTCH ASSY, shoe	1	
20	09140-28004	NUT, shoe clutch	1	
21	09140-12039	NUT, clutch housing	1	
22	09164-12020	WASHER, clutch housing nut	1	
23	27601-46G00	V-BELT, drive	1	

FIG. 17



FIG. 17 TRANSMISSION

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	24131-46G10	SHAFT, drive	1	
2	24150-46G12	SHAFT, idle	1	
3	09181-12167	WASHER, idle shaft LH 12x20x1.0		
4	09283-20060	OIL SEAL, drive shaft 20x28x5	1	
5	09262-10017	BEARING, drive shaft LH 10x26x8	1	
6	08110-62040	BEARING, drive shaft middle	1	
7	08113-62010	BEARING, idle shaft RH	1	
8	08110-60020	BEARING, drive shaft RH	1	
9	08113-62010	BEARING, idle shaft LH	1	
10	09280-10015	O-RING, drive shaft	1	
11	24141-46G20	SHAFT, rear axle	1	
12	24371-46G10	GEAR, final driven	1	
13	09262-22027	BEARING, axle shaft RH	1	
14	64841-28E00	OIL SEAL, axle shaft oil 27x40x6	1	
15	08331-31229	CIRCLIP, final driven gear	2	
16	08110-62030	BEARING, axle shaft LH	1	
17	24751-07900	RETAINER, axle shaft bearing	1	
18	02122-0616A	SCREW, bearing retainer	2	

FIG. 18



FIG. 18 KICK STARTER

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	26210-46G01	SHAFT, kick starter	1	
2	26212-46G00	SPRING, kick shaft	1	
3	09160-14053	WASHER, kick sh otr 14.5X22x08	1	
4	26213-46F00	BUSH, kick shaft	1	
5	09283-14008	SEAL, kick starter sh otr 14x24x6	1	
6	26200-46G10	GEAR ASSY, kick starter dri	1	
7	26231-33G00	STARTER, kick RH	1	
8	09140-12037	NUT, kick starter	1	
9	09164-12020	WASHER, kick starter nut lock	1	
10	08331-31149	CIRCLIP, kick shaft	1	
11	26300-33G60	LEVER ASSY, kick starter	1	
12	26314-33G00	BOLT, kick starter	1	

FIG. 19



FIG. 19 STARTING MOTOR

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31100-46G00	STARTER ASSY, starting	1	
2	31130-20G00	HOLDER SET, brush	1	
3	31131-20G00	BRUSH SET	1	
4	31135-19D00	SRPING	2	
5	31143-49040	O RING	1	
6	31151-20G00	HOUSING SET	1	
7	31156-98E00	O RING	1	
8	31170-19B10	WASHER SET	1	
9	31264-13E00	O RING	1	
10	31280-20G00	BOLT SET	2	
11	31143-49040	O RING	2	
12	01547-0625A	BOLT, motor	2	
13	08361-3506A	NUT	1	

3

FIG. 20



FIG. 20 MAGNETO

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
	32100-46G20	MAGNETO ASSY	1	
1	32101-46G20	STATOR	1	
2	32102-46G20	ROTOR	1	
3	02142-0510A	SCREW, sensor	2	
4	07130-0520A	BOLT, magneto stator	3	
5	31792-33G10	NUT, magneto rotor	1	
6	08341-31039	KEY, magneto rotor	1	
7	09404-06429	CLAMP, magneto lead wire	1	

FIG. 21



FIG. 21 ELECTRICAL

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-32G00	RECTIFIER ASSY	1	
2	02142-0612A	SCREW, rectifier	1	
3	31800-31C00	RELAY ASSY, starter motor	1	
4	08361-3506A	NUT, starter motor	2	
5	32900C46G10C000	CDI UNIT	1	
6	32980-20G00	CUSHION, cdi unit	1	
7	33410-46G00	COIL ASSY, ignition	1	
8	01550-0616A	BOLT, ignition coil	1	
9	33510-20E00T	CAP, spark plug	1	
10	33541-13H00	SEAL, spark plug	1	
11	33542-33G00	SEAL, high tension cord	1	
12	33810-46G01	WIRE, starter motor	1	
13	31861-48B10	CAP, starter motor	1	
14	31861-11500	CAP, starter relay	1	

4

FIG. 22



FIG. 22 BATTERY

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33610-20GA0	BATTERY (FTZ5S, 12V 3.5AH)	1	
2	33651-46G00	BAND, battery	1	
3	33652M46G00	PROTECTOR, battery	1	
4	33652M46G10	PROTECTOR, battery	1	
5	33652-46G20	PROTECTOR, battery	1	

FIG. 23



FIG. 23 SPEEDOMETER

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34100-46G60	SPEEDOMETER ASSY	1	
2	34111-46G00	CASE, lower speedometer	1	
3	34150-46G00	CASE, upper speedometer	1	
4	34125-46G40	PLATE, speedometer	1	
5	34173-46G40	SOCKET ASSY, speedometer	1	
6	09471-12077	BULB (12V, 1.7 W)	3	
7	02112-74108	SCREW	2	
8	34383-09400	SCREW	3	
9	34910-46G11	CABLE, speedometer	1	
10	34930-46G00	GUIDE, speedometer cable	1	
11	02142-0612A	SCREW, guide cable	1	
12	03541-0520A	SCREW, speedometer	3	
13	34188-46G00	CUSHION, speedometer	1	

4

FIG. 24



FIG. 24 HEADLAMP

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	35100-46G41	HEADLAMP ASSY	1	
2	35121-46G40	UNIT, headlamp	1	
3	35124-46G40	LENS, headlamp	1	
4	09471-12171	BULB (12V, 30/30 W)	1	
5	35171-46G00	SOCKET, headlamp	1	
6	09136-05051	SCREW, headlamp	1	
7	35382-33G00	CUSHION, headlamp	1	

FIG. 25



FIG. 25 FRONT TURN LAMP

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	35601-46G00	LAMP ASSY, front turn RH	1	
2	35602-46G00	LAMP ASSY, front turn LH	1	
3	35612-46G00	LENS, turn RH	1	
4	35632-46G00	LENS, turn LH	1	
5	35613-46G00	GASKET	2	
6	35618-46G00	SOCKET, front turnsignal R	1	
7	35638-46G00	SOCKET, front turnsignal L	1	
8	09471-12203	BULB (12V, 10 W)	2	
9	03541-0512A	SCREW, front turnsignal	4	
10	38610-09410	RELAY ASSY, turnsignal	1	

4

FIG. 26



FIG. 26 REAR COMBINATION LAMP

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	35710-46G20	LAMP ASSY, rear combination	1	
2	35712-46G00	LENS, tail/stop	1	
3	35713-46G00	GASKET	1	
4	35912-46G00	LENS, inner	1	
5	09471-12119	BULB (12V, 18/5 W)	1	
6	09471-12203	BULB (12V, 10 W)	2	
7	03541-0516A	SCREW	2	
8	09148-05045	NUT, rear comb lamp	2	
9	03541-0512A	SCREW , rear comb lamp	2	

FIG. 27



FIG. 27 WIRING HARNESS

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36610-46G50	HARNESS, wiring	1	
2	09481-10501	FUSE (10A)	2	
3	09404-06433	CLAMP, wiring (L:80)	2	
4-1	09407-11401	CLAMP, wiring	2	
4-2	09407-14403	CLAMP, wiring (L:125)	4	
4-3	09407-18402	CLAMP, wiring (L:165)	3	
4-4	09407-25401	CLAMP, wiring (L:235)	3	
5	37109-46G00	LOCK SET, steering	1	
6	37100-46G00	LOCK ASSY, steering	1	
7	01550-06163	BOLT, steering lock	2	
8	38500-09G01	HORN ASSY	1	
9	01550-0612A	BOLT, horn	1	
10	37420M09E00	SWITCH, dimmer	1	
11	37510-10E00	SWITCH, turnsignal	1	
12	37520-09G30	SWITCH, horn	1	
13	37310-09G40	SWITCH, starter	1	

4

FIG. 28



FIG. 28 FRAME

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41100M46G30-019	FRAME	1	
2	41180-46G10-019	BRACKET, crankcase	1	
3	41170-46G10	SPACER, crankcase bracket	1	
4	09319-12060	BUSH, crankcase	2	
5	41189-46G00	BOLT, crankcase	1	
6	08319-3112A	NUT	1	
7	41185-46G10	CUSHION, swing stop	2	
8-1	46210-46G00T106	HANDLE, pillion rider	1	N.Titan Black
8-2	46210-46G00T904	HANDLE, pillion rider	1	B.White
9	01500-0825B	BOLT, pillion rider handle	2	
10	09160-08010T	WASHER	2	

FIG. 29



FIG. 29 STAND

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	42100-46G00-019	STAND, center	1	
2	42211-16F11	SHAFT, center stand	1	
3	08322-0110A	WASHER, center stand	1	
4	04111-3020A	COTTER PIN	1	
5	09443-17006	SPRING, center stand	1	
6	42251-46G10	BOLT, center stand spring	1	
7	09321-10002	CUSHION	1	
8	42310-46G00-019	STAND, prop	1	
9	09443M14022	SPRING, prop stand	1	
10	42341-09G00T	BOLT, prop stand	1	
11	08319-3110A	NUT, prop stand	1	

FIG. 30



FIG. 30 FOOTREST

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	43611-25G00	BAR, pillion footrest RH	1	
2	43621-25G00	BAR, pillion footrest LH	1	
3	43811-46G00-334	BRACKET, pillion footrest	1	
4	43821-46G00-334	BRACKET, pillion footrest	1	
5	43812-25G00	BOLT, pillion footrest	4	
6	43816-33E21	PLATE, pillion footrest RH	1	
7	43826-33E22	PLATE, pillion footrest LH	1	
8	09208-06003	PIN, pillion footrest	2	
9	09440-05005T	SPRING, pillion footrest	2	
10	06112-07004	BALL, pillion footrest	2	
11	08332-11043	E-RING	2	

FIG. 31



FIG. 31 FUEL TANK

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	44110M46G20-019	TANK, fuel	1	
2	44210-35014	CAP, fuel tank	1	
3	01550-0612A	BOLT, fuel tank	4	
4	34810-46G10	GAUGE ASSY, fuel level	1	
5	02142-0512A	SCREW, fuel gauge	4	
6	44300-46G00	COCK ASSY, fuel	1	
7	09168-06026	GASKET, fuel cock	2	
8	02142-0616A	SCREW, fuel cock	2	
9	44422-46G01	HOSE, fuel	1	
10	09401-09403	CLIP, fule hose	2	
11	44425-46G10	HOSE, vacuum	1	
12	09401-08401	CLIP, vacuum hose	2	
13	44427-46G00	CLIP	1	

4

FIG. 32



FIG. 32 SEAT

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	45100-46G11-432	SEAT	1	
2	45149-46G20	CUSHION, seat mount front	2	
3	45149-46G20	CUSHION, seat mount center	2	
4	45149-35410	CUSHION, seat mount rear	2	
5	45285-46G10	BRACKET, seat hinge	1	
6	45215-09G20	PIN, seat support front	1	
7	08310-0006A	NUT, seat support front	2	
8	08332-1106A	E-RING, seat hinge pin	1	
9	45280M46G20	CABLE, seat lock	1	
10	45288-20G00	GUIDE, cable	1	
11	45289-09G10	PLATE, seat lock NO.2	1	
12	95700-14810	LOCK, seat	1	
13	45700-09G10	BRACKET, striker support	1	
14	02112-0610A	SCREW, striker support bracket	2	
15	45160-46G00	COVER COMP, seat trim	1	
16	45254-46G00	WEATHERSTRIP, seat	1	

FIG. 33



FIG. 33 FRAME COVER

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	47111-46G20-106	COVER, frame RH	1	N.Titan Black
1-2	47111-46G20-904	COVER, frame RH	1	B.White
2-1	47211-46G20-106	COVER, frame LH	1	N.Titan Black
2-2	47211-46G20-904	COVER, frame LH	1	B.White
3	47311-46G10-502	COVER, front	1	
4	09320-08018	CUSHION, frame cover	2	
5	09148-05038	NUT, frame cover front	6	
6	09139-06145	SCREW, frame cover side	2	
7	03541-0516A	SCREW, frame cover front	4	
8	02142-0616A	SCREW, upper	1	
9	03541-1516A	SCREW, frame cover rear	2	

FIG. 34



FIG. 34 FRONT LEG SHIELD

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	48111-46G20-106	SHIELD LEG, front	1	N.Titan Black
1-2	48111-46G20-158	SHIELD LEG, front	1	Hyper Pink
1-3	48111-46G20-280	SHIELD LEG, front	1	Macho B.Blue
2	48137-46G00-501	SHIELD LEG, lower front	1	
3	03541-0516A	SCREW, rack lower	2	
4	09148-05038	NUT, leg shield	5	
5	48150-46G10T	BRACE, leg shield	1	
6	01550-0612A	BOLT, leg brace	2	
7	09409-07336	CLIP, leg lower	2	
8	09136-06002	SCREW, shield leg front	3	

FIG. 35



FIG. 35 REAR LEG SHIELD

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48121-46G00-501	SHIELD, leg rear	1	
2	09113-06008	BOLT, leg rear	4	
3	48138-46G02-501	SHIELD LEG, lower	1	
4	03541-05163	SCREW, leg lower front	6	
5	09148-05038	NUT, leg lower / legshield	4	
6	09139-06145	SCREW, leg rear	2	
7	02142-0612A	SCREW, leg lower	1	

4

FIG. 36



FIG. 36 LEG SHIELD COVER

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	92111-46G10-502	COVER, leg shield	1	
2	03541-0516A	SCREW, cvr leg shield	6	
3	92161-46G00-502	RACK, leg shield	1	
4	03541-0525A	SCREW, rack leg	2	
5	92171-32G00-502	HOOK, leg shield	1	
6	02142-0612A	SCREW, hook leg shied	1	
7	09320-08028	CUSHION, leg shield front	2	
8	09160-06079	WASHER, leg shield hook	1	

FIG. 37



FIG. 37 LUGGAGE BOX

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	92211-46G10	BOX, luggage	1	
2	03541-0512A	SCREW, battery box lid	1	
3	92212-46G00	LID, battery	1	
4	03541-0512A	SCREW, luggage box	4	
5	09148-05038	NUT, battery box lid	1	
6	39410-46G00	TERMINAL, power source	1	
7	94910-46G00	BAG ASSY, luggage box	1	

FIG. 38



FIG. 38 FRONT FENDER

REF.NO	PART NO.	DESCRIPTION	Q'TY	
1-1	53111-46G00-106	FENDER, front	1	N.Titan Black
1-2	53111-46G00-158	FENDER, front	1	Hyper Pink
1-3	53111-46G00-280	FENDER, front	1	Macho B.Blue
2	01550-0612A	BOLT, front fender bracket	3	
3	09169-06071T	WASHER, front fender	3	

FIG. 39



FIG. 39 HANDLE BAR

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	56110-46G10T	HANDLE BAR	1	
2	51358-09G00T	STOPPER, handle bar	1	
3	09103-10126	BOLT, handle bar stopper	1	
4	08319-3110A	NUT, handle bar stopper	1	
5	56500-09G20	MIRROR ASSY, rear view RH	1	
6	56600-09G20	MIRROR ASSY, rear view LH	1	
7	56520-09G20	COVER, nut	2	
8	56632-09G20	NUT, rear view mirror	2	
9	58300-46G30	CABLE ASSY, throttle	1	
10	02112-0512A	SCREW, throttle cable	1	
11	58410M46G10	CABLE ASSY, starter	1	
12-1	09407-18402	CLAMP, cable	2	
12-2	09407-19401	CLAMP, cable	1	
13	58510M46G00	CABLE, rear brake	1	
14	09209-11002	PIN, rear brake cable	1	
15	09150-06001	NUT, rear brake cable adjuster	1	
16	58562-46G00	SPRING, rear brake cable	1	
17	58575-46G00	PLATE, rear brake	1	
18	02112-0610A	SCREW, rear brake cable plate	1	
19	58577-46G20	CLAMP, rear brake cable crk fr	1	
20	58577-46G30	CLAMP, rear brake cable crk rr	1	
21	58474-46G40	GUIDE, starter cable	1	

4

FIG. 40



FIG. 40 HANDLE COVER

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	56311-46G31-106	COVER, handle front	1	N.Titan Black
1-2	56311-46G31-158	COVER, handle front	1	Hyper Pink
1-3	56311-46G31-280	COVER, handle front	1	Macho B.Blue
2	56321-46G20-502	COVER, handle rear	1	
3	02142-0512A	SCREW , handle cover front	1	
4	03541-0416A	SCREW , handle cover rr side	4	
5	03511-0516A	SCREW, handle cover rr up.	2	

FIG. 41



FIG. 41 HANDLE LEVER

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	57110-09G01	GRIP, throttle	1	
2	57100-09G01	CASE ASSY, throttle	1	
3	02112-05203	SCREW	1	
4	57300-46G00	LEVER ASSY, front brake	1	
5	57421-46G00	LEVER, brake	1	
6	08319-2106B	NUT, brake lever	1	
7	57431-29C20	BOLT, lever pivot	1	
8	57460-17C01	SWITCH ASSY, stop	1	
9	57465-17C00	SCREW	1	
10	57211-09G00	GRIP, LH	1	
11	57500-46G21	LEVER ASSY, rear brake	1	
12	57621-46G00	LEVER, rear brake	1	
13	57470-09G00	SWITCH ASSY, rear brake	1	
14	08319-2106B	NUT	1	
15	57431-09G20	BOLT	1	
16	57511-46G00	HOLDER, brake lever	1	
17	59671-09G00	HOLDER	1	
18	01550-06258	BOLT, brake lever holder	2	
19	58711-09G00	HOLDER, starter cable	1	
20	09139-05057	SCREW, starter cable holder	1	
21	58721-23F01	LEVER CHOKE	1	
22	09164-07001	WASHER	1	
23	02112-75163	SCREW	1	

4

FIG. 42



FIG. 42 FRONT CALIPER

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	59100-46G00	CALIPER ASSY, front	1	
2	69000-46800	PISTON SET	1	
3	59100-46800	.SEAL SET, piston	1	
4	69100-46800	PAD SET	1	
5	69345-20G00	PIN, hanger	1	
6	59115-20G00	SPRING	1	
7	59386-13A00	BOOT	1	
8	59382-14500	PIN	1	
9	69720-46G00	BRACKET	1	
10	59388-00B20	NUT, torque	1	
11	59146-20G00	PLUG, pin	1	
12	59387-46G00	PIN, bolt	1	
13	59303-14500	BOOT	1	
14	59121-01A00	BLEEDER	1	
15	59122-01A00	CAP, bleeder	1	
16	09103-08107	BOLT	2	
17	59145-37F00	RING, stopper	1	

FIG. 43



FIG. 43 FRONT MASTER CYLINDER (UY125 S)

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	59600-46G20	CYLINDER ASSY, front master	1	
2	59600-46800	PISTON & CUP SET	1	
3	59666-44300	BOOT	1	
4	59664-32F00	PROTECTOR	1	
5	59667-44B00	DIAPHRAGM	1	
6	59668-21D20	PLATE, diaphragm	1	
7	69669-21D20	CAP	1	
8	69689-49300	SCREW	2	
9	59671-36500	HOLDER	1	
10	59675-02FA0	BOLT	2	
11	09168-10033	WASHER, brake fluid	4	
12	09360-10042	BOLT, brake fluid	2	
13	59480-46G00	HOSE, front brake	1	
14	59260-46G00	CLAMP, front brake hose	1	
15	01550-0610A	BOLT, brake hose clamp	2	
16	59240-46G00	GUIDE, front brake hose	1	
17	01550-0625A	BOLT, brake hose guide	1	

4

FIG. 44



FIG. 44 REAR FENDER

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	63111-46G00-501	BODY, rear fender rear	1	
2	09148-05038	NUT	2	
3	01550-0612A	BOLT, rear fender NO.2	2	
4	63112-46G00-501	BODY, rear fender front	1	
5	03541-0516A	SCREW, rear fender	6	
6	63185-46G00	BRACKET, band battery	1	
7	03541-0512A	SCREW, band battery bracket	1	
8	96510-46G10T	TOOL SET	1	
9	47435-46G00	BAND, tool	1	
10	61361-09G20	BOLT, rear fender NO.1	2	
11	31805-46G00	BRACKET, starter relay	1	
12	03541-0516A	SCREW, bracket relay	1	

FIG. 45



FIG. 45 DAMPER

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	51103-46G10	DAMPER ASSY, front fork RH	1	
2	51104-46G10	DAMPER ASSY, front fork LH	1	
3	51130-46G10	TUBE, outer RH	1	
4	51140-46G10	TUBE, outer LH	1	
5	51153-23F00	OIL SEAL	2	
6	51156-43010	RING, stopper	2	
7	51173-23F00	DUST SEAL	2	
8	51147-16510	BOLT, cylinder	2	
9	51148-41310	GASKET	2	
10	51146-46G00	CYLINDER	2	
11	51177-35400	SPRING, cylinder	2	
12	51196-39140	RING, piston	2	
13	51110-46G00	TUBE COMP, inner	2	
14	51171-46G00	SPRING, rebound	2	
15	51181-37B00	O-RING	2	
16	51351-09G10	CAP, front fork	2	

4

FIG. 46



FIG. 46 FRONT FORK BRACKET

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	51410-46G10	STEM, steering	1	
2	51622-35400	RACE, out lower	1	
3	51451-42G00	BOLT, stem	4	
4	51612-09G00	RACE, inner lower	1	
5	06111-06004	BALL, steering steel	50	
6	51611-09G10	RACE, inner upper	1	
7	51621-07H00	RACE, outer upper	1	
8	51643-06001	DUST SEAL, steering upper	1	
9	51631-09G00	NUT, steering stem	2	
10	09166-24001	WASHER	1	

FIG. 47



FIG. 47 FRONT WHEEL

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	54111-46G20-414	WHEEL, front (1.4 X 14)	1	
2	08123-63007	BEARING, front hub	2	
3	09180-10148	SPACER, front hub bearing	1	
4	54711-04701	AXLE, front	1	
5	54750-46100	SPACER, front axle RH	1	
6	08319-3110A	NUT, front axle	1	
7	54600-46G00	BOX ASSY, speedometer gear	1	
8	59211-09G00	DISC, front brake	1	
9	59218-09G00	BOLT , front brake disc	4	
10	55110-46G00	TIRE, front (70/90-14)	1	
11	55200-46G00	TUBE ASSY, wheel inner	1	

4

FIG. 48



FIG. 48 REAR ABSORBER

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	62100-46G20-R93	ABSORBER ASSY, rear shock	1	
2	01570-1035A	BOLT, rear shock lower	1	
3	08310-0010A	NUT, rear shock upper	1	
4	09160-12061	WASHER, rear shock upper	1	
5	09160-10001	WASHER, rear shock upper outer	1	

FIG. 49



FIG. 49 REAR WHEEL

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	64150-46G20-414	WHEEL COMP, rear (1.6 x14)	1	
2	64401-46800	SHOE, brake rear	1	
3	55421-09D10	SPRING, brake shoe	2	
4	64440-46G00	CAM, rear brake	1	
5	64451-46G00	LEVER, rear brake cam	1	
6	01550-06358	BOLT, brake cam lever	1	
7	54494-09G00	NUT, brake cam lever	1	
8	64492-46G00	PLATE, indicator	1	
9	09160-16049	WASHER, rear axle	1	
10	09159-16020	NUT, rear axle	1	
11	65110-46G00	TIRE, rear (80/90-14)	1	
12	65200-46G00	TUBE ASSY, wheel inner	1	

FIG. 50



FIG. 50 TAPE SET

REF.NO	PART NO.	DESCRIPTION	Q'TY	REMARKS
	68100M46G50-106	TAPE SET, body cover	1	N.Titan Black
	68100M46G50-158	TAPE SET, body cover	1	Hyper Pink
	68100M46G50-280	TAPE SET, body cover	1	Macho B.Blue
1-1	68140M46G50-106	TAPE SET, side cover RH /	1	N.Titan Black
1-2	68140M46G50-158	TAPE SET, side cover RH /	1	Hyper Pink
1-3	68140M46G50-280	TAPE SET, side cover RH /	1	Macho B.Blue
2-1	68235M46G60-106	TAPE , side cover “STEP”	2	N.Titan Black & Mac
2-2	68235M46G60-158	TAPE , side cover “STEP”	2	Hyper Pink
3-1	68659M46G50-106	TAPE SET, shield legside, upper	1	N.Titan Black
3-2	68659M46G50-158	TAPE SET, shield legside, upper	1	Hyper Pink
3-3	68659M46G50-280	TAPE SET, shield legside, upper	1	Macho B.Blue
4-1	68652M46G50-106	TAPE SET, shield legside, lower	1	N.Titan Black
4-2	68652M46G50-158	TAPE SET, shield legside, lower	1	Hyper Pink
4-3	68652M46G50-280	TAPE SET, shield legside, lower	1	Macho B.Blue
5-1	68315M46G50-106	TAPE, ”SUZUKI”, shield legside	2	N.Titan Black
5-2	68315M46G50-158	TAPE, ”SUZUKI”, shield legside	2	Hyper Pink
5-3	68315M46G50-280	TAPE, ”SUZUKI”, shield legside	2	Macho B.Blue
6-1	68678M46G50-106	TAPE, shield leg front, upper	1	N.Titan Black
6-2	68678M46G50-158	TAPE, shield leg front, upper	1	Hyper Pink
6-3	68678M46G50-280	TAPE, shield leg front, upper	1	Macho B.Blue
7-1	68657M46G50-106	TAPE, shield leg front, lower	1	N.Titan Black
7-2	68657M46G50-158	TAPE, shield leg front, lower	1	Hyper Pink
7-3	68657M46G50-280	TAPE, shield leg front, lower	1	Macho B.Blue
8-1	68285M46G50-106	TAPE, “STEP”, shield leg front	1	N.Titan Black
8-2	68285M46G50-158	TAPE, “STEP”, shield leg front	1	Hyper Pink
8-3	68285M46G50-280	TAPE, “STEP”, shield leg front	1	Macho B.Blue
9	68190M21E99E000	“ S “ Suzuki emblem	1	

PART NO.	FIG. NO.	REF.NO.
00000		
01421-0630A	2	7
01421-0695B	3	4
01500-0825B	28	9
01500-1016A	4	17
01547-0610A	2	8
01547-0612B	5	4
01547-0616A	13	17
01547-0616B	5	37
01547-0620A	1	7
01547-0620A	11	16
01547-0620A	15	10
01547-0620A	15	12
01547-0620B	5	16
01547-0620B	5	36
01547-0620B	9	8
01547-0625A	11	15
01547-0625A	13	18
01547-0625A	19	12
01547-0625B	5	5
01547-0625B	5	10
01547-0625B	5	40
01547-06307	5	22
01547-0630B	5	6
01547-0630B	5	20
01547-0635A	2	14
01547-0655A	4	6
01547-0660B	5	21
01547-0665B	5	17
01547-0675A	4	7
01550-0610A	43	15
01550-0612A	14	13
01550-0612A	27	9
01550-0612A	31	3
01550-0612A	34	6
01550-0612A	38	2
01550-0612A	44	3
01550-06163	27	7
01550-0616A	21	8
01550-06258	41	18
01550-0625A	43	17
01550-06358	49	6
01550-0812A	4	19
01550-0812A	4	23
01550-0830B	5	34
01550-0835B	12	9
01550-0845B	5	35
01570-1035A	48	2
02112-04083	10	14
02112-0512A	39	10
02112-05203	41	3
02112-0610A	32	14
02112-0610A	39	18
02112-1625A	14	18
02112-1625B	14	16
02112-35127	10	20
02112-74108	23	7
02112-75163	41	23
02122-06128	2	17
02122-0616A	17	18
02122-06258	13	2
02142-0510A	20	3
02142-0512A	31	5
02142-0512A	40	3
02142-0612A	21	2
02142-0612A	23	11
02142-0612A	35	7
02142-0612A	36	6
02142-0616A	31	8
02142-0616A	33	8
03141-0516A	5	32
03511-0516A	40	5
03541-0416A	40	4
03541-0512A	25	9
03541-0512A	26	9
03541-0512A	37	2
03541-0512A	37	4
03541-0512A	44	7
03541-05163	35	4
03541-0516A	26	7
03541-0516A	33	7
03541-0516A	34	3
03541-0516A	36	2
03541-0516A	44	5
03541-0516A	44	12
03541-0516B	14	17
03541-0520A	23	12
03541-0520B	11	10
03541-0525A	36	4
03541-0620A	14	15
03541-1516A	33	9
04111-3020A	29	4
04211-11129	2	10
04211-11129	3	5
06111-06004	46	5
06112-07004	30	10
07130-0520A	20	4
07130-0612A	7	8
07130-0820B	12	2
08110-60020	17	8
08110-62030	17	16
08110-62040	17	6
08113-62010	17	7
08113-62010	17	9
08113-69050	8	3
08123-63007	47	2
08310-0006A	32	7
08310-0010A	48	3
08313-2010A	14	19
08316-1008B	2	5
08316-1012B	4	22
08319-2106B	41	6
08319-2106B	41	14
08319-3110A	29	11
08319-3110A	39	4
08319-3110A	47	6
08319-3112A	28	6
08322-0110A	29	3
08331-31149	18	10
08331-31229	17	15
08332-11043	30	11
08332-1106A	32	8
08341-31039	20	6
08361-3506A	19	13
08361-3506A	21	4
09103-06247	9	4
09103-08107	42	16
09103-10126	39	3
09106-05028T	8	5
09106-07003	1	3
09108-08272	3	3
09113-06008	35	2
09136-05051	24	6
09136-06002	34	8
09139-05057	41	20
09139-06091	12	5
09139-06145	33	6
09139-06145	35	6
09140-12037	18	8
09140-12039	16	21
09140-28004	16	20
09148-05038	33	5
09148-05038	34	4
09148-05038	35	5
09148-05038	37	5
09148-05038	44	2
09148-05045	26	8
09150-06001	39	15
09159-16020	49	10
09160-06028	11	14
09160-06028	12	6
09160-06079	36	8
09160-08010T	28	10
09160-08163	12	12
09160-08164	2	6
09160-10001	48	5
09160-12061	48	4
09160-14053	18	3
09160-16049	49	9
09164-07001	41	22
09164-12020	16	22
09164-12020	18	9
09166-24001	46	10
09168-06004	9	5
09168-06026	31	7
09168-08008	4	20
09168-08008	4	24
09168-10002	4	18
09168-10017	14	20
09168-10033	43	11
09169-06071T	38	3
09180-06166	15	8
09180-06256	12	7
09180-08151	12	11
09180-10148	47	3
09180-19013	6	5
09181-12167	17	3
09181-35026	6	19-2
09181-35103	6	19-1
09181-35104	6	19-3
09181-35105	6	19-4
09181-35106	6	19-5
09181-35107	6	19-6
09181-35108	6	19-7
09206-08008	5	7
09206-08008	5	11
09206-08008	5	23
09206-08008	8	7
09206-08008	4	8
09206-13007	7	2
09208-06003	30	8
09209-11002	39	14
09261-05005	8	6
09261-10007	7	5
09262-10017	17	5
09262-15035	16	14
09262-15041	8	2
09262-22027	17	13
09262-25122	6	11
09262-35079	6	10
09263-20093	16	15
09263-28034-0B0	6	9
09280-10015	17	10
09280-13007	13	14
09280-14003	4	16
09280-17003	5	25
09280-54001	13	15
09283-14008	18	5
09283-20060	17	4
09283-22033	6	12
09283-25095	6	13
09284-34003	16	16
09289-05008	8	22
09319-10032	4	5
09319-12060	28	4
09320-07014	15	10
09320-08018	33	4
09320-08028	36	7
09320-08051	12	8
09320M12032	12	10
09321-10002	29	7
09360-10042	43	12
09381-10004	2	2
09381-14001	6	18
09381-24005	16	17
09401-08401	31	12
09401-09403	31	10
09401-10401	4	14
09401-14301	11	12
09401-15101	15	12
09404-06429	20	7
09404-06433	27	3
09407-11401	27	4-1
09407-14403	27	4-2
09407-18402	27	4-3
09407-18402	39	12-1
09407-19401	39	12-2
09407-25401	27	4-4
09409-07336	34	7
09409-08308	5	39
09440-03007	7	6
09440-05005T	30	9
09443-17006	29	5
09443M14022	29	9
09471-12077	23	6
09471-12119	26	5
09471-12171	24	4
09471-12203	25	8
09471-12203	26	6
09481-10501	27	2
09482M00568	2	11
09491-97007	10	15
09492-15011	10	21
100000		
11110-46G00	2	1
11135-46G00	2	4
11141-46G00	2	3
11171-46G00	1	1
11173-46G00	1	2

5

PART NO.	FIG. NO.	REF.NO.
11177-46G00	1	6
11180-46G00	1	5
11186-46G00	1	8
11191-27E20	1	4
11211-33G01-0F0	3	1
11241-46G00	3	2
11307-46G00	5	28
11310-46820	4	1
11315-46G00	4	2
11315-46G00	4	4
11320-46830	4	3
11325-46G00	4	9
11326-46G00	4	10
11327-46G00	4	11
11340-46G00	5	1
11346-46G00	5	3
11347-46G00	5	38
11351-46G01	5	18
11361-46G10	5	29
11362-46G00	5	30
11363-46G00	5	31
11373M46G00	5	41
11381-46G00	5	12
11382-46G10	5	13
11383-46G00	5	14
11385-46G00	5	27
11386-46G00	5	15
11390-46G00	5	33
11410-46G00	5	26
11431-46G00	5	8
11432-46G00	4	13
11482-46G00	5	2
11483-46G00	5	19
11484-46G00	5	9
11971-33G01	5	24
11971-46G00	4	15
12100-46G10-0F0	6	14
12111-46G11-0F0	6	15
12140-33G10	6	16
12151-20G00	6	17
12160-46811	6	6
12161-46G00-0C0	6	7
12200-46G01	6	1
12210-46G00-0A0	6	8
12221-46G00	6	2
12261-46G00	6	3
12511-33G00	6	4
12600-46820	7	3
12611-46G00	7	1
12633-05300	7	4
12649-30D00	7	7
12710-46G00	8	1
12725-33G00	8	11
12741-33G10	8	4
12760-20G00	9	1
12771-33G10	9	2
12811-28G10	9	3
12830-46G00	9	6
12837-46G00	9	7
12840-33G30	8	12
12842-49201	8	13
12843-27A00	8	14
12861-33G10	8	15
12862-33G00	2	16
12911-28G20	8	16
12912-33G10	8	17
12921-28G40	8	18
12931-09G00	8	19
12932-09G00	8	20
12933-09G00	8	21
12951-33G10	8	8
12954-33G00	8	9
12955-33G00	8	10
13110-46G10	2	12
13125-46G00	2	13
13170-46G10	2	15
13200-46G30	10	1
13240-47E00	10	17
13247-25G00	10	42
13254-20010	10	13
13258-23F00	10	12
13258-46G00	10	36
13267-46G00	10	22
13268-47070	10	27
13271-24D00	10	23
13274-46G00	10	40
13275-46G00	10	46
13278-47090	10	38
13279-23F30	10	26
13291-29900	10	30
13295-29900	10	31
13341-46G00	10	16
13342-46G00	10	18
13370-46G00	10	28
13375-88C00	10	29
13382-23F00	10	8
13383-46G30	10	11
13387-23F00	10	10
13411-46G00	10	35
13412-46G00	10	19
13417-01010	10	34
13418-12F40	10	6
13418-43410	10	33
13432-44120	10	41
13481-23F00	10	7
13502-46G00	10	4
13502-46G10	10	3
13507-25G00	10	2
13509-17C00	10	44
13533-98410	10	9
13551-46G00	10	45
13573-46G00	10	5
13593-46G00	10	47
13601-04188	10	39
13602-38A10	10	24
13602-47090	10	37
13617-12C00	10	48
13681-04010	10	32
13683-36A00	10	25
13683-46G00	10	49
13686-46G00	10	43
13700-46G01	11	1
13720-46G01	11	2
13740-46G00	11	13
13746-46G00	11	3
13780-46G01	11	4
13821-46G00	11	5
13824-18910	11	6
13826-46G00	11	7
13853-46G00	11	11
13871-09G00	11	8
13881-46G00	11	9
14181M46G00	12	1
14310-46G40T	12	3
14780-46G00	12	4

PART NO.	FIG. NO.	REF.NO.
16310-46G00	13	8
16331-46G00	13	3
16400-46G00	13	1
16421-20E00	13	6
16422-20E00	13	4
16422-46G10	13	7
16423-20E00	13	5
16510-05240	13	9
16512-09G00	13	10
16519-09G00	13	16
16520-09402	13	11
16523-20E00	13	12
16524-46G00	13	13
16912-46G00	4	12
17110-46G00	14	1
17116-46G00	14	2
17121-46G00	14	3
17122-46G00	14	4
17123-46G00	14	5
17125-46G00	14	14
17131-46G00	14	6
17132-46G00	14	10
17133-46G00	14	11
17134-20E00	14	12
17134-46G00	14	8
17135-46G00	14	9
17141-46G00	14	7
18450-06G00	15	1
18461-46G01	15	2
18510-46G00	15	3
18531-46G00	15	4
18711-46G01	15	6
18750-46G00	15	5
18762-46G00	15	7

200000

PART NO.	FIG. NO.	REF.NO.
21111-33G00	16	1
21120-33G00	16	2
21125-33G00	16	3
21210-33G00	16	4
21220-20E21	16	18
21240-33G00	16	5
21243-33G00	16	6
21245-33G00	16	7
21248-33G00	16	8
21249-33G00	16	9
21431-33G00	16	10
21471-33G00	16	11
21481-14F00	16	12
21501-46G00	16	19
21650-33G10	16	13
24131-46G10	17	1
24141-46G20	17	11
24150-46G12	17	2
24371-46G10	17	12
24751-07900	17	17
26200-46G10	18	6
26210-46G01	18	1
26212-46G00	18	2
26213-46F00	18	4
26231-33G00	18	7
26300-33G60	18	11
26314-33G00	18	12
27601-46G00	16	23
31100-46G00	19	1
31130-20G00	19	2
31131-20G00	19	3
31135-19D00	19	4
31143-49040	19	5
31143-49040	19	11
31151-20G00	19	6
31156-98E00	19	7
31170-19B10	19	8
31264-13E00	19	9
31280-20G00	19	10
31792-33G10	20	5
31800-31C00	21	3
31805-46G00	44	11
31861-11500	21	14

300000

PART NO.	FIG. NO.	REF.NO.
31861-48B10	21	13
32100-46G20	20	
32101-46G20	20	1
32102-46G20	20	2
32800-32G00	21	1
32900C46G10C000	21	5
32980-20G00	21	6
33410-46G00	21	7
33510-20E00T	21	9
33541-13H00	21	10
33542-33G00	21	11
33610-20GA0	22	1
33651-46G00	22	2
33652-46G20	22	5
33652M46G00	22	3
33652M46G10	22	4
33810-46G01	21	12
34100-46G60	23	1
34111-46G00	23	2
34125-46G40	23	4
34150-46G00	23	3
34173-46G40	23	5
34188-46G00	23	13
34383-09400	23	8
34810-46G10	31	4
34910-46G11	23	9
34930-46G00	23	10
35100-46G41	24	1
35121-46G40	24	2
35124-46G40	24	3
35171-46G00	24	5
35382-33G00	24	7
35601-46G00	25	1
35602-46G00	25	2
35612-46G00	25	3
35613-46G00	25	5
35618-46G00	25	6
35632-46G00	25	4
35638-46G00	25	7
35710-46G20	26	1
35712-46G00	26	2
35713-46G00	26	3
35912-46G00	26	4
36610-46G50	27	1
37100-46G00	27	6

5

PART NO.	FIG. NO.	REF.NO.
37109-46G00	27	5
37310-09G40	27	13
37420M09E00	27	10
37510-10E00	27	11
37520-09G30	27	12
38500-09G01	27	8
38610-09410	25	10
39410-46G00	37	6
400000		
41100M46G30-019	28	1
41170-46G10	28	3
41180-46G10-019	28	2
41185-46G10	28	7
41189-46G00	28	5
42100-46G00-019	29	1
42211-16F11	29	2
42251-46G10	29	6
42310-46G00-019	29	8
42341-09G00T	29	10
43611-25G00	30	1
43621-25G00	30	2
43811-46G00-334	30	3
43812-25G00	30	5
43816-33E21	30	6
43821-46G00-334	30	4
43826-33E22	30	7
44110M46G20-019	31	1
44210-35014	31	2
44300-46G00	31	6
44422-46G01	31	9
44425-46G10	31	11
44427-46G00	31	13
45100-46G11-432	32	1
45149-35410	32	4
45149-46G20	32	3
45149-46G20	32	2
45160-46G00	32	15
45215-09G20	32	6
45254-46G00	32	16

PART NO.	FIG. NO.	REF.NO.
45280M46G20	32	9
45285-46G10	32	5
45288-20G00	32	10
45289-09G10	32	11
45700-09G10	32	13
46210-46G00T106	28	8-1
46210-46G00T904	28	8-2
47111-46G20-106	33	1-1
47111-46G20-904	33	1-2
47211-46G20-106	33	2-1
47211-46G20-904	33	2-2
47311-46G10-502	33	3
47435-46G00	44	9
48111-46G20-106	34	1-1
48111-46G20-158	34	1-2
48111-46G20-280	34	1-3
48121-46G00-501	35	1
48137-46G00-501	34	2
48138-46G02-501	35	3
48150-46G10T	34	5
500000		
51103-46G10	45	1
51104-46G10	45	2
51110-46G00	45	13
51130-46G10	45	3
51140-46G10	45	4
51146-46G00	45	10
51147-16510	45	8
51148-41310	45	9
51153-23F00	45	5
51156-43010	45	6
51171-46G00	45	14
51173-23F00	45	7
51177-35400	45	11
51181-37B00	45	15
51196-39140	45	12
51351-09G10	45	16
51358-09G00T	39	2
51410-46G10	46	1
51451-42G00	46	3
51611-09G10	46	6

PART NO.	FIG. NO.	REF.NO.
51612-09G00	46	4
51621-07H00	46	7
51622-35400	46	2
51631-09G00	46	9
51643-06001	46	8
53111-46G00-106	38	1-1
53111-46G00-158	38	1-2
53111-46G00-280	38	1-3
54111-46G00-414	47	1
54494-09G00	2	9
54494-09G00	49	7
54600-46G00	47	7
54711-04701	47	4
54750-46100	47	5
55110-46G00	47	10
55200-46G00	47	11
55421-09D10	49	3
56110-46G10T	39	1
56311-46G31-106	40	1-1
56311-46G31-158	40	1-2
56311-46G31-280	40	1-3
56321-46G20-502	40	2
56500-09G20	39	5
56520-09G20	39	7
56600-09G20	39	6
56632-09G20	39	8
57100-09G01	41	2
57110-09G01	41	1
57211-09G00	41	10
57300-46G00	41	4
57421-46G00	41	5
57431-09G20	41	15
57431-29C20	41	7
57460-17C01	41	8
57465-17C00	41	9
57470-09G00	41	13
57500-46G21	41	11
57511-46G00	41	16
57621-46G00	41	12
58300-46G30	39	9
58410M46G10	39	11
58474-46G40	39	21
58510M46G00	39	13
58562-46G00	39	16
58575-46G00	39	17

PART NO.	FIG. NO.	REF.NO.
58577-46G20	39	19
58577-46G30	39	20
58711-09G00	41	19
58721-23F01	41	21
59100-46800	42	3
59100-46G00	42	1
59115-20G00	42	6
59121-01A00	42	14
59122-01A00	42	15
59145-37F00	42	17
59146-20G00	42	11
59211-09G00	47	8
59218-09G00	47	9
59240-46G00	43	16
59260-46G00	43	14
59303-14500	42	13
59382-14500	42	8
59386-13A00	42	7
59387-46G00	42	12
59388-00B20	42	10
59480-46G00	43	13
59600-46800	43	2
59600-46G20	43	1
59664-32F00	43	4
59666-44300	43	3
59667-44B00	43	5
59668-21D20	43	6
59671-09G00	41	17
59671-36500	43	9
59675-02FA0	43	10
600000		
61361-09G20	44	10
62100-46G20-R93	48	1
63111-46G00-501	44	1
63112-46G00-501	44	4
63185-46G00	44	6
64150-46G20-414	49	1
64401-46800	49	2
64440-46G00	49	4
64451-46G00	49	5
64492-46G00	49	8

PART NO.	FIG. NO.	REF.NO.
64711-09G00	4	21
64841-28E00	17	14
65110-46G00	49	11
65200-46G00	49	12
68100M46G50-106	50	
68100M46G50-158	50	
68100M46G50-280	50	
68140M46G50-106	50	1-1
68140M46G50-158	50	1-2
68140M46G50-280	50	1-3
68190M21E99E000	50	9
68235M46G60-106	50	2-1
68235M46G60-158	50	2-2
68285M46G50-106	50	8-1
68285M46G50-158	50	8-2
68285M46G50-280	50	8-3
68315M46G50-106	50	5-1
68315M46G50-158	50	5-2
68315M46G50-280	50	5-3
68652M46G50-106	50	4-1
68652M46G50-158	50	4-2
68652M46G50-280	50	4-3
68657M46G50-106	50	7-1
68657M46G50-158	50	7-2
68657M46G50-280	50	7-3
68659M46G50-106	50	3-1
68659M46G50-158	50	3-2
68659M46G50-280	50	3-3
68678M46G50-106	50	6-1
68678M46G50-158	50	6-2
68678M46G50-280	50	6-3
69000-46800	42	2
69100-46800	42	4
69345-20G00	42	5
69669-21D20	43	7
69689-49300	43	8
69720-46G00	42	9
900000		

PART NO.	FIG. NO.	REF.NO.
92111-46G10-502	36	1
92161-46G00-502	36	3
92171-32G00-502	36	5
92211-46G10	37	1
92212-46G00	37	3
94910-46G00	37	7
95700-14810	32	12
96510-46G10T	44	8

5